

HOW TO RESET MAINTENANCE ALARM

VA388

Enter in the menu from the button on the bottom right of the screen.



Select the icon to access in the technical settings page.





Select the maintenance page



Press the button until the "Maintenance Reset" message appears.



| VA358 | |
|--|--|
| Enter in the menu from the button on the bottom right of the screen. |  |
| Select the "technical settings" page. |  |
| From the technical settings page, select the "maintenance" page. |  |
| Press the button "RESET" until the deliveries number flashes one time; in this way the maintenance alarm is reset. |  |
| ADONIS | |
| From the menu, select the maintenance page. |  |
| Press and hold the RESET button for 10 seconds to reset the internal counter. |  |