




HOW TO RESET THE MAINTENANCE ALARM ON EAGLE ONE


Press the icon on the top left of the screen to enter inside the menu




Select "Technical Settings", insert the PIN **1936** and click the symbol .




Select "Maintenance"



Select "Alarms"



To reset the maintenance alarm:

- keep the symbol  pressed for 5 seconds, until it becomes grey to reset the maintenance counter
- Set the date for the next maintenance alarm

