



ERROR LIST

Error N°	ERROR TYPE
1	<i>HEATING PROBE OPEN</i>
2	<i>HEATING PROBE CC</i>
5	<i>SCALE DISCONNECTED</i>